

Field	Type	Purpose
name	string	Name of the ACE in ixsys.config
tag	int	ID of ACE assigned by Resource Manager
ue	int	Bitmask of microengines running the ACE
bname	string	TAG name that the microblock uses
ccbase	ix_base_t	Handle for crosscall service